


EXCHANGE AREA BOUNDARY MAP




Code

- Central Office
- Exchange Area Boundary Line
- - - Switched Company Boundary Line
- ▨ Open Territory
- ⬅-+⬆ Present Customer in Foreign Territory
- Town Line

Distance of Boundary Line Less than 1/4 Mile  
 from Highway or Section Line indicated in Feet

Exchange Area Boundary Map




Code

- Central Office
- Exchange Area Boundary Line
- Switched Company Boundary Line
- Open Territory
- Present Customer in Foreign Territory
- Town Line

Distance of Boundary Line Less than 1/4 Mile  
from Highway or Section Line indicated in Feet

PSCW acceptance by letter  
File No. 646 GHE  
EFFECTIVE 7-29-63


# Exchange Area Boundary Map



## Code

- Central Office
  - Exchange Area Boundary Line
  - - - Switched Company Boundary Line
  - ▨ Open Territory
  - ⊕ Present Customer in Foreign Territory
  - Town Line
- Distance of Boundary Line Less than 1/4 Mile  
from Highway or Section Line indicated in Feet

Exchange Area Boundary Map



Code

- Central Office
- Exchange Area Boundary Line
- - - Switched Company Boundary Line
- ▨ Open Territory
- ◄-|◄ Present Customer in Foreign Territory
- Town Line

Distance of Boundary Line Less than 1/4 Mile  
 from Highway or Section Line indicated in Feet